

HANGING INSTRUCTIONS

We recommend that these wallcoverings should be installed by a professional paperhanger.

NOTE

The highest quality of workmanship is employed in the production of these wallcoverings. The wallcovering is silk screened by hand and cannot have the mechanical precision of machine printed wallpaper. Careful inspections are made before shipment, however final inspection and approval are the ultimate responsibility of the customer. Correct design and color should be checked before the wallcovering is hung. It is important that all rollage be marked with the same dyelot number to guarantee color uniformity.

CAUTION

Due to the possibility of differences in dyelots , we recommend that all wallpapers and fabrics be in your possession before any work is started. No claims will be accepted on wallcoverings after they have been processed in any way by the purchaser.

IMPORTANT WALL PREPARATION

Walls should be smooth, dry, and free from dirt and grease. Walls should be oiled to make sure there is no loose paint. Size with 100% vinyl adhesive (R-35) is suggested. Allow to dry.

ADHESIVE

Use a clear ready mix adhesive. Follow manufacturer's instructions carefully. Pasted sheet should be booked and set aside to relax at least 2 minutes before installation. Wash adhesive completely from the surface of the wallcovering immediately after each strip is hung.